

Top view of the Volvo C303 hold at mid level

scale 1:10 cm

For your own engineering you only need to print the second page. Additional hints see here:

The dimensions of the free space are taken at the inner side from every frame member around the walls. The frames on each wall are not included. The sheet metal is 3 – 4 cm more outward, but that space is not easy to use.

This level 50 cm above the back floor is the level with the maximum undisturbed space just above the engine cover. At this height the lower box from steel ends and the aluminium plates begin.

Just below this level the handles and locks of the doors do protrude some cm into the free space.

Consider inaccurate measurement of about half a cm...

Attention: Page is DIN-A4. Don't scale while printing.

Sectional view of the Volvo C303 hold (waistline 50 cm above rear floor) (scale 1:10 cm)

